

DIGITAL SCANNING TIPS

BEFORE SCANNING:

Pack 1 or 0 retraction cord below margin line of prep, ensuring the margin stays visible for the duration of the scan.

Dry the area as much as possible and turn your head lamp or overhead light off to avoid reflections during scanning.

DURING SCAN:

Have assistant blow air onto and around prep site to maintain a dry field for the duration of the scan.

POST SCAN:

Digitally mark margins and section dies; this allows you a chance to review your scan before the patient leaves. Don't worry about perfection during this step. Margin line can be edited as necessary once the scan has been received and accepted.

Ensure you've taken and included a bite scan with your scanned case.

CUSTOM ABUTMENTS:

Ensure the scan body/scan flag is fully seated by x-ray before proceeding to the scanning step.

If the scan body intersects with adjacent teeth and will not fully seat, please contact your scan body manufacturer for further instruction. Cases with a modified scan body will not be accepted.

Please include brand of scan body in notes.



Classic★**Craft**
DENTAL LABORATORY

877.552.7238 Fax: 912.355.1007
2807-B Roger Lacey Drive, Savannah, GA 31404
classiccraftdental.com

If you have any questions contact Adam Smith at
Classic Craft Dental Laboratory at 877.552.7238.